## NATEF TASK SHEET --- SECTION A.8 A.6,8 P-2

## Tune4: REMOVE, INSPECT, AND INSTALL DISTRIBUTOR CAP AND IGNITION ROTOR

Are your sparks getting there all the time?

Student:		Date:	Period:
VIN:	Year:	Make:	Model:
Engine:	Transmission: Production Date:		
OBJECTIVE:	Student will remove, inspect, evaluate and install distributor cap and ignition rotor.		
MATERIALS:	<ol> <li>EYE PROTECTION</li> <li>Hand tools</li> <li>Vehicle (see instructor)</li> </ol>		
	WEAR EYE PROTECTION! Watch power point/video Tune 4.  Find firing order in All-Data or Mitchell-on-Demand and print out and attach to back of task sheet. Locate ignition distributor. Draw diagram of spark plug wire locations. Remove clips or loosen screws and remove distributor cap and rotor. Unhook all plug wires to remove cap. Inspect inside and outside of distributor cap. Look for cracks, burned spots, corrosion, rust, and dirt. Inspect ignition rotor for same types of defects. Show cap and rotor to instructor. Note findings below. Install cap, install rotor, and reconnect wires with correct firing order. Install screws or clips to hold down cap. Start vehicle and check for smooth idle. Recommend reuse or replacement of cap & rotor below.  CAP & ROTOR APPEARANCE:  (Dirty, cracked, burnt, corroded, rusty, new, clean, broken, etc)		
			-
FIRING ORDE			ERVICE INFORMATION SYSTEM
<u>RECOMMEND</u>	ATION: CIRCLE ONE REPLA	ACE CAP & KO	OTOR REUSE CAP & ROTOR
WHY?			
INCTRLCTO	R'S SIGN OFF:		
INSTRUCTO	K S SIGN OFF.		INSTRUCTOR'S EVALUATION
Draw cap and number plug wire locations:		cations: Dei	monstrates Mastery
			rformed Satisfactorily
			pable, Needs Practice
			sisted in Performing
		Exp	posure/Observation
(Char	w distributor rotor rotation di	inaction)	